**Location of the connection pannel.**



Datalogger

IR Sensors

Datalogger

IR Sensors

12VPo
GND

SIG
GND ⟩ SOUTH EAST

SIG
GND ⟩ NORTH EAST

SIG
GND ⟩ SOUTH WEST

SIG
GND ⟩ NORTH WEST